

Please take a few moments to answer our questions. They will help us develop new products for the future.

1 Do you own any other air movement products?

- Air conditioner
- Ceiling fan
- Pedestal fan
- Humidifier
- Air purifier
- Fan heater
- Other, please specify _____
- Table fan
- Tower fan
- Floor fan
- No (please go to question 3)

2 Which brand of fan are you replacing or adding to?

- Dyson
- Mistral
- Dimplex
- IXL
- Other, please specify _____
- Heller
- Coral Breeze
- Sunbeam
- Don't know

3 Why did you choose to buy a Dyson fan?

(Please rate each statement on a scale of 1 to 5, 1 being the least important and 5 the most important).

	1	2	3	4	5
Dyson reputation	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Smooth, powerful airflow	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Previous experience of Dyson	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Features	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to clean	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Price/special offer	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Store staff recommendation	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Latest model/technology	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Aesthetics	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Friend/family recommendation	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

4 Where did you first hear about Dyson fans?

- From friends and family
- From a TV/magazine/internet advert
- Saw it in a store catalogue
- Saw it in a store
- Recommended by salesperson
- Online blog/review article
- Email from Dyson

5 Where did you look for additional information?

- Dyson website
- Online reviews and forums
- Retail staff
- Retail catalogue
- No additional research was done

6 Do you own other Dyson products?

- Vacuum cleaner
- Handheld
- Handstick
- Fan
- No

7 Where do you intend to use the Dyson fan? (Please tick as many boxes as applicable)

- Bedroom
- Lounge
- Dining room
- Kitchen
- Study
- Other, please specify _____

8 What is your household income?

- Less than \$45,000
- Between \$45,000 – \$75,000
- Between \$75,000 – \$100,000
- Over \$100,000

9 To which age group do you belong?

- 16 – 24
- 25 – 34
- 35 – 44
- 45 – 54
- 55 – 64
- 65+

10 Would you recommend a Dyson fan to your friends and family?

- Yes
- No

11 Do you have children?

- Under 5 years
- 5+ years
- No children
- Children no longer at home
- Pregnant

12 Which best describes your home?

- Up to 2 beds
- 3-4 beds
- More than 4 beds

AUSTRALIAN CONSUMER LAW

The details of the Dyson guarantee are set out below. In addition to your rights under the Dyson guarantee, we also provide the following statement as required by the Australian Consumer Law: In Australia, your Dyson fan comes with statutory guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have your Dyson fan repaired or replaced if it fails to be of acceptable quality and the failure does not amount to a major failure.

DYSON 2 YEAR GUARANTEE

TERMS AND CONDITIONS

- Terms and conditions of your Dyson 2 year guarantee.
- The Dyson guarantee becomes effective from the date of purchase.
- All work will be carried out by Dyson Appliances (Aust) Pty Ltd., Avery Robinson Ltd. (NZ), Singapore's authorised agent - Service @Home Pte Ltd. Indonesia's authorised agent - PT Higienis Indonesia or their authorised agents.
- Any parts replaced will become the property of Dyson Appliances (Aust) Pty Ltd., Avery Robinson Ltd. (NZ), Dyson Singapore Pte Ltd. or PT Higienis Indonesia.
- The repair and replacement of the fan under Dyson guarantee will not extend the Dyson guarantee period.
- The Dyson guarantee provides benefits which are additional to, and do not affect, your statutory rights and remedies as a consumer.
- You must provide proof of (both the original and any subsequent) delivery/ purchase before any work can be carried out on your Dyson fan. Without this proof, any work carried out pursuant to the Dyson guarantee and any associated delivery charges (both to and from us) will be at your cost, subject to your statutory rights and remedies as a consumer. Please keep your receipt or delivery note.

WHAT IS COVERED

- Your Dyson guarantee covers:
 - The repair or replacement of your fan if your fan is found to be defective due to faulty materials, workmanship or function within 2 years of purchase or delivery (if any part is no longer available or out of manufacture Dyson will replace it with a functional replacement part).
 - Use of the fan in the country of purchase.

WHAT IS NOT COVERED

- Under your Dyson guarantee, Dyson shall not be liable for costs of repair or replacement of a product incurred as a result of:
 - Normal wear and tear.
 - Accidental damage, faults caused by negligent use or care, neglect, careless operation or handling of the fan which is not in accordance with this manual.
 - Damage as a result of use not in accordance with the rating plate.
 - Blockages – please refer overleaf for details on how to unblock the fan.
 - Use of parts and accessories other than those produced or recommended by Dyson.
 - Damage from external sources such as transit, weather, electrical outages or power surges.
 - Repairs or alterations carried out by parties other than Dyson or its authorised agents.
 - Failures caused by circumstances outside Dyson's control.

If your Dyson guarantee does not apply, you may have statutory rights and remedies available to you as a consumer.

If you are in doubt as to what is covered by your Dyson guarantee, please call the Dyson Customer Care Helpline on:
 Australia 1800 239 766
 New Zealand 0800 397 667
 Singapore 7000 435 7546
 Indonesia 021 707 39766

Remember: Always disconnect plug from mains before inspecting for problems. If the fan will not operate, first check the mains socket has electricity supply and that the plug is properly inserted into the socket.

REGISTERING YOUR GUARANTEE

- To help us ensure you receive prompt and efficient service, please register as a Dyson fan owner. There are three ways to do this:
 - Online (Australia and New Zealand only)
 AU: www.dyson.com.au/register
 NZ: www.dyson.co.nz/register
 - By calling the Dyson Customer Care Helpline.
 - By completing and returning the enclosed form to us by mail.
- This will confirm ownership of your Dyson fan in the event of an insurance loss, and enable us to contact you if necessary.

DYSON CUSTOMER CARE

If you have a query about your Dyson fan call the Dyson Customer Care Helpline and quote your serial number, or contact us via the Dyson website. The serial number can be found on the rating plate which is on the base of the product. Most queries can be solved over the phone by one of our Dyson Customer Care Helpline staff. If your Dyson fan needs servicing, call the Dyson Customer Care Helpline to discuss the available options. To enable us to carry out work on your Dyson fan, please contact the Dyson Customer Care Helpline to obtain a reply paid address in your state (available in Australia only).

If your fan is under Dyson guarantee and the repair or replacement is covered, it will be repaired or replaced at no cost. If the repair or replacement is found not to be covered under the Dyson guarantee, the repair or replacement of the fan and any associated delivery charges (both to and from us) will be at your cost, subject to your statutory rights and remedies as a consumer.

DYSON CUSTOMER CARE DETAILS

If there are any queries, please call the Dyson Customer Care Helpline
 AU: 1800 239 766 (Mon-Fri 8:00am to 6:00pm EST, Sat-Sun 8:30am to 4:00pm EST)
www.dyson.com.au
 NZ: 0800 397 667 (Mon-Fri 8:30am to 5:00pm)
www.dyson.co.nz
 SG: 7000 435 7546 (Mon-Fri 9:00am to 6:00pm)
www.dyson.com.sg
 ID: 021 707 39766 (Mon-Fri 9:00am to 5:00pm)
www.dyson.co.id

ABOUT YOUR PRIVACY

Dyson may use your information provided for future marketing and research purposes (including sending commercial electronic messages) and may disclose it to third parties for the purposes of providing the services you have requested, or to our business partners or professional advisers. If you wish to access your personal information or see our full privacy policy, please contact us at customer-care@dyson.com.au

DISPOSAL INFORMATION

Dyson products are made from high grade recyclable materials. Please dispose of this product responsibly and recycle where possible.

When your Dyson fan reaches the end of its life, we are responsible for its safe disposal. You can send your old Dyson fan back to us (at our cost) and we will organise for it to be recycled.*

*Please note that not all parts are recyclable. Recycling of parts is subject to the capabilities of 3rd party suppliers. Available in Australia only.

Simply:

1. Box up your old Dyson fan.
2. Take your package to your local post office and send to the address below:

Dyson We Recycle
 Reply Paid 83215
 Dyson Service Centre
 Unit 6 & 7, 7-11 Parraweena Rd
 Taren Point, NSW 2229.

PRODUCT INFORMATION

Please note: Small details may vary from those shown.



Dyson Customer Care

If you have a query about your Dyson fan, call the Dyson Customer Care Helpline with your serial number and details of where and when you bought the fan, or contact us via the Dyson website. The serial number can be found on the rating plate which is on the base of the product.

AU **Dyson Customer Care**
customer-care@dyson.com.au
 1800 239 766

Dyson Appliances (Aust) Pty Ltd.,
 PO Box 2835,
 Taren Point, NSW 2229,
 Australia
www.dyson.com.au

NZ **Dyson Customer Care**
dyson@averyrobinson.co.nz
 0800 397 667

Avery Robinson Ltd.,
 Unit F, 151D Marua Road,
 Ellerslie, Auckland 1051,
 New Zealand
www.dyson.co.nz

SG **Dyson Customer Care**
singapore@dyson.com
 7000 435 7546

Service @ Home Pte. Ltd.,
 2 Leng Kee Road,
 #04-09A Thye Hong Centre,
 Singapore 159086
www.dyson.com.sg

ID **Dyson Customer Care**
service@higienis.com
 021 707 39766

PT. Higienis Indonesia
 Permata Plaza Top Floor, TF-04,
 Jl. M. H. Thamrin Kav. 57,
 Jakarta 10350
 Indonesia
www.dyson.co.id

www.dyson.com


OPERATING MANUAL



ASSEMBLY


1 Lower the loop amplifier onto the base, aligning the arrows.

2 Once aligned, turn the loop amplifier clockwise to lock.



IMPORTANT
 Remove the clear film once the machine is assembled

REGISTER YOUR DYSON 2 YEAR GUARANTEE TODAY



THANK YOU FOR YOUR TIME



Your Dyson fan will be covered for parts and labour for 2 years from the date of purchase, as detailed in the terms of the Dyson guarantee set out in this Dyson Operating Manual.

If you have a query about your Dyson fan, call the Dyson Customer Care Helpline quoting the serial number and details of where and when you bought the fan. The serial number can be found on the rating plate which is on the base of the product.

Most queries can be solved over the phone by one of our Dyson Customer Care Helpline staff (details below).

Visit our website to register your Dyson full parts and labour guarantee online (Australia and New Zealand only).

AU: www.dyson.com.au/register
 NZ: www.dyson.co.nz/register

Note your serial number for future reference.



For illustration purposes only.

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE


When using an electrical appliance, basic precautions should always be followed, including the following:

WARNING

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- This fan is not intended for use by young children or persons with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction by a responsible person concerning use of the fan to ensure that they can use the fan safely.
- Young children should be supervised to ensure that they do not play with the fan.
- The loop amplifier must be fitted securely before operating this fan. Do not dismantle the fan or use without the loop amplifier fitted.
- Do not operate any fan with a damaged cable or plug. Discard fan or return to a Dyson authorised service agent for examination and/or repair. If the supply cable is damaged, it must be replaced by Dyson, our service agent or similarly qualified persons in order to avoid a hazard.
- If the fan is not working as it should or has been damaged, do not use; contact the Dyson Customer Care Helpline.
- Do not run the cable under carpeting. Do not cover the cable with throw rugs, runners or similar coverings. Arrange the cable away from traffic areas and where it will not be tripped over.
- Turn 'OFF' all controls before unplugging. Unplug from outlet when not in use for extended periods. To avoid a tripping hazard, safely coil the cable.
- Do not unplug by pulling on the cable. To unplug, grasp the plug, not the cable.
- Suitable for dry location ONLY. Do not use outdoors or on wet surfaces and do not expose to water or rain.
- Do not handle plug or fan with wet hands.
- Do not stretch the cable or place the cable under strain. Keep the cable away from heated surfaces.
- Do not put any object into openings or the inlet grille. Do not use with any opening blocked; keep free of dust, lint, hair and anything that may reduce airflow.
- Do not use near furnaces, fireplaces, stoves or other high temperature heat sources.
- Do not use in conjunction with or directly next to an air freshener or similar products.
- Do not use any cleaning agents or lubricants on this fan. Unplug before cleaning or carrying out any maintenance.
- Use only as described in this manual. Do not carry out any maintenance other than that shown in this manual, or as advised by the Dyson Customer Care Helpline.
- The use of an extension cable is not recommended.
- Always carry the fan by the body, do not carry it by the loop amplifier.

READ AND SAVE THESE INSTRUCTIONS




Do not pull on the cable. Do not store near heat sources. Do not use near naked flames. Do not carry by the loop amplifier.

3 EASY WAYS TO REGISTER YOUR DYSON 2 YEAR GUARANTEE


<p>REGISTER ONLINE</p> <p>Visit our website to register your Dyson full parts and labour guarantee online (Australia and New Zealand only).</p> <p>AU: www.dyson.com.au/register NZ: www.dyson.co.nz/register</p>	<p>REGISTER BY PHONE</p> <p>Call our dedicated Helpline.</p> <p>AU 1800 239 766 NZ 0800 397 667 SG 7000 435 7546 ID 021 707 39766</p>	<p>REGISTER BY MAIL</p> <p>Complete and return the form to Dyson in the envelope supplied.</p>
--	---	---

Tilt function




Adjust base forward or backward for required airflow angle.

Cleaning




To clean, wipe with a dry or damp cloth.




Do not use detergents or polishes to clean the fan.

Clearing blockages



Look for blockages in the air inlet holes. Use a soft brush to remove debris.



Look for blockages in the small aperture inside the loop amplifier. Use a soft brush to remove debris.

dyson

GUARANTEE FORM

Date of purchase / / Country of purchase Australia New Zealand Singapore Indonesia

Serial number

Title Surname

First name

Address

Postcode

email

Telephone Mobile

Store of purchase

Privacy Act
 Dyson may use this information for future marketing and research purposes (including sending commercial electronic messages) and may disclose it to third parties for the purposes of providing the services you have requested or to our business partners or professional advisers. If you wish to access your personal information or see our full privacy policy, please contact us at customercare@dyson.com.au. If you do not wish to receive marketing information by these methods from Dyson please tick this box.

3 EASY WAYS TO REGISTER YOUR DYSON 2 YEAR GUARANTEE

<p>REGISTER ONLINE</p> <p>Visit our website to register your Dyson full parts and labour guarantee online (Australia and New Zealand only).</p> <p>AU: www.dyson.com.au/register NZ: www.dyson.co.nz/register</p>	<p>REGISTER BY PHONE</p> <p>Call our dedicated Helpline.</p> <p>AU 1800 239 766 NZ 0800 397 667 SG 7000 435 7546 ID 021 707 39766</p>	<p>REGISTER BY MAIL</p> <p>Complete and return the form to Dyson in the envelope supplied.</p>
--	---	---